












































X18771	15 pin	
1 Yellow	Sub 1 +	
2 Blue/Red	Sub 2 +	
3 Yellow/Violet	LH Rear loudspeaker + (ground on touring)	
4 White	Radio on/antenna signal	
5 Blue/Gray	RH rear loudspeaker +	
6 Brown	Sub 4 -	
7 Blue/Brown	Sub 3 -	
8 Red/Green	Terminal 30 connects to Fuse 56	
9 Brown	Sub 1 -	
10 Blue/Brown	Sub 2 -	
11 Yellow/Gray	Touring LH rear +	
12 Blue/Violet	Touring LH rear -	
13 Blue	Sub 4 +	
14 Blue/White	Sub 3 +	
15 Brown	Terminal 31 connects to ground point	

X18772	18 Pin	
1 Not Used		
2 Black/Brown	Low freq. negative (-) signal - Tranceiver/charging electronics	
3 Not Used		
4 Not Used		
5 White/Yellow/Gray	I-bus Signal Line - splice X18344	
6 Not Used		
7 Not Used		
8 Brown/Orange	RH front speaker (-) - connects to Radio	
9 Brown/Orange	LH front speaker (-) - connects to Radio	
10 Not Used		
11 Black/white	Low freq. voltage (+) signal - Tranceiver/charging electronics	
12 Not Used		
13 White/Brown	Telephone mute signal - Tranceiver/charging electronics	
14 Not Used		
15 White/Green	Telephone ON signal - Tranceiver/charging electronics	
16 Not Used		
17 Blue/Red	RH front speaker (+) - connects to Radio	
18 Yellow/Red	LH front speaker (+) - connects to Radio	

X18773	26 pin	
1 Yellow/Red	LH front woofer +	
2 Yellow/Brown	LH front woofer -	
3 Not Used		
4 Blue/Brown	RH front mid-range -	
5 Yellow/White	LH front mid-range +	
6 Not Used		
7 Not Used		
8 Not Used		
9 Blue/White	RH front mid-range +	
10 Yellow/Brown	LH front mid-range -	
11 Blue/Black	Right rear mid-range speaker/tweeter +	
12 Blue/Green	RH front tweeter +	
13 Blue/Red	RH front woofer +	
14 Yellow/Green	LH front tweeter +	
15 Yellow/Brown	LH front tweeter -	
16 Yellow/Gray	Left rear mid-range speaker/tweeter -	
17 Not Used		
18 Not Used		
19 Yellow/Black	Left rear mid-range speaker/tweeter +	
20 Not Used		
21 Not Used		
22 Not Used		
23 Not Used		
24 Blue/Gray	Right rear mid-range speaker/tweeter -	
25 Blue/Brown	RH front tweeter -	
26 Blue/Brown	RH front tweeter +	